


Alat za ravnanje kuke menjača

1602/5



Profili





628355	392	250	338	89	189	M10 x 1	168	959

* Fotografije proizvoda su simbolične. Sve dimenzije su u mm, a težina u gramima. Sve navedene dimenzije mogu odstupati u granicama tolerancija.


Upotreba (slike)



Indicator can be mounted on the tool body.



Kad se alat postavi na ram, podesite dužinu donjeg produžetka tako da indikator bude na spoljnoj ivici rama.




Alat se isporučuje u paketu sa uloškom.



Organizovan i uvek pri ruci.



Dodatni deo omogućava i rad na manjim prečnicima točka.



Indikator i dugme za podešavanje.



Donji deo alata pričvršćuje se za nosač zadnjeg menjača.